


四層



粉紅四層櫃
H-705V/4 3400
W57 L47 H94



杏色四層櫃
H-200V/4 4000
W57 L48 H94



繽紛四層櫃
H-132V/4 3800
W60 L48 H98




藍色花漾四層櫃
H-159V/4 4200
W60 L48 H100

五層



藍色五層櫃
H-705V/5 4200
W57 L47 H117



淺藍五層櫃
H-200V/5 4600
W57 L48 H117



繽紛五層櫃
H-132V/5 4600
W60 L48 H122



白色花漾五層櫃
H-159V/5 5200
W60 L48 H124

鞋櫃



卡其



米白




淺灰



四層鞋櫃
H-286V 4800
W70 L35 H85




恐龍四層櫃
H-468V/4 5600
W60 L48 H100



藍蝶四層櫃
H-468V/4 5000
W60 L48 H100



童趣四層櫃
H-915V/4 5200
W70 L48 H105




黑色花漾四層櫃
H-259V/4 5800
W70 L48 H105



金色樹葉五層櫃
H-468V/5 6000
W60 L48 H124



彩虹五層櫃
H-915V/5 6200
W70 L48 H130



仿竹紋五層櫃
H-259V/5 7000
W70 L48 H130

兒童
衣櫃



仿竹紋衣櫃
H-727V 7000
W70 L50 H135

玩具
收納



海洋八格櫃
H-935V/4 6000
W70 L48 H105



簡易收納櫃
H-051V/3 2400
W40 L48 H83
H-051V/4 2800
W40 L48 H106
H-051V/5 3200
W40 L48 H122

各式冰桶

露營郊遊 · 戶外活動 · 釣魚裝備

各式容量超齊全！
組合購買更優惠！



85L



60L



60L



45L



35L



12L

85公升冰桶 0-243V 5000
L74 W47 H52

60公升冰桶 0-777V 3200
L66 W41 H46

60公升冰桶 0-242V (附輪) 3600
L70 W41 H44

45公升冰桶 0-241V 2400
L61 W41 H41

35公升冰桶 0-240V 2000
L56 W38 H37

12公升冰桶 0-238V 900
L38 W26 H27



14公升飲料冰桶
0-931V 1300
L32 W33 H40



垃圾桶
0-273V 800
L30 W38 H45



垃圾桶
0-218V 700
L40 W35 H44



三層碗櫥(大)
H-380V 2600
L60 W40 H121



三層碗櫥(小)
H-379V 2200
L47 W36 H110



提籃
0-383V 300
L46 W32 H25



提籃(大)
0-134V 180
L38 W28 H42



提籃(小)
0-133V 140
L34 W24 H28



禮物籃(大)
0-1128V 150
L40 W28 H37



禮物籃(小)
0-1127V 100
L34 W24 H31



免組裝

教學影片



閃電X型伸縮曬衣架

X-301B 1800

W150~240 L72 H127
完全折疊



展開後可達240cm



閃電X型伸縮曬衣架(加強)

X-301 3000

W150~240 L72 H127
不鏽鋼 完全折疊 含防風勾

加強版
實際重量高達7公斤

收納後體積極小



X 型



展開後可達210cm



X型伸縮曬衣架

X-302 2000

W160~210 L60 H150



支架可延伸40cm




防風勾X型伸縮曬衣架

X-304 2600

W160~210 L60 H150

蝴蝶型



蝴蝶曬衣架 (圓管一般型)

X-201 1800

W165 L53 H94
收納 W104 L58



蝴蝶曬衣架 (方管一般型)

X-203 2600

W163 L53 H95
收納 W104 L58



蝴蝶曬衣架 (方管加強型)

X-205 3600

W163 L55 H124
收納 W132 L61